

NEW XIAO ELEVATOR GROUP

Zhejiang SURAPID Elevator Co.,Ltd.

Website: www.sjlift.com

This book is a general information publication, and we reserve the right to change the product technology and description at any time. Any words and sentences in this book, regardless of their literal meaning or meaning, are not responsible for the use and quality of any product, or the expression and modification of any purchase and sale contract. The appearance of the product is for reference only, the extra product is fall provided.





FULL RANGE OF PRODUCT SOLUTIONS BOOSTING NEW MOMENTUM OF URBAN LIFE

| ABOUT SURAPID | |
|-----------------------------------|----|
| Brand Strength | 0 |
| Intelligent Manufacturing Factory | 03 |
| Product Superiority | 05 |

PASSENGER ELEVATOR SERIES

| Chuancheng Series Machine-room Passenger Elevators | 21 |
|---|----|
| Jierui Series Machine-room-less Passenger Elevators | 31 |
| Jieyun Series Panoramic Elevators | 45 |
| Jierun Series Hospital Elevators | 59 |
| Function List of Passenger Elevators | 71 |

FREIGHT ELEVATOR SERIES Jieda Series | Freight Elevators 77 83 Function List of Freight Elevators **HOME ELEVATOR SERIES** Jieshang Series | Home Elevators 85 Function List of Home Elevators 98 **Escalator Series** Jiexun Series | Escalators and Moving Sidewalks 101

Specification List of Escalators and Moving Sidewalks

110

Over-200-Meter-High Exemplary Test Tower A Total Height of 208 Meters 190m Above the Ground and 18m Under the Ground SURAPID | 01

BRAND STRENGTH

SURAPID Elevator Co., Ltd. is a subsidiary of NEW XI'AO ELEVATOR GROUP. With a factory of over 158 thousand square meters and a total investment of over 1 billion yuan, SURAPID is a professional modern elevator manufacturer with integration of design, manufacturing, sales, installation, and maintenance. As a member of NEW XI'AO ELEVATOR GROUP, SURAPID has absorbed the Group's more than 40 years of experience in elevator manufacturing and development. We have a 208-meter-high ultra-high-speed elevator test tower, a technical research and development team of more than 300 people, and lots of modern production equipment, such as flexible thick and thin sheet metal production lines, YASKAWA spray coating robots, cold rolled sheet metal landing door machines, ABB robot welding lines, and escalator and truss production lines. We spare no effort to build a lean manufacturing system, providing customers with high-grade, precision, advanced products, and services. After many years of development, SURAPID offers more than 10 thousand products a year and is already in the front rank of domestic elevator brands in terms of industrial scale and comprehensive strength.

"Helping customers succeed" is SURAPID's service goal. To meet customer demands, SURAPID constantly improves the aftersales service system, applies the AI system and the SURAPID cloud remote monitoring system for comprehensive interaction, supports real-time uploading of operation and fault data, and focuses on setting an example in the industry in terms of service.

We have a professional management platform, a strong technical team, an experienced after-sales service team and a nationwide sales and maintenance network. We provide all-weather hotline services and strictly conduct 100% full product inspection. We offer safe, intelligent, green elevators and escalators to customers.



INTELLIGENT MANUFACTURING FACTORY

Jiaxing Intelligent Industrial Park—A Model Factory in the Intelligent Era



The industrial park covers an area of 237 mu (15.8 hectares), combining smart technology with aesthetic design.

SURAPID I 03

MASTER CORE TECHNOLOGIES OF THE WHOLE INDUSTRIAL CHAIN

Core Parts Safety Parts

SURAPID'S THREE CORE PARTS

SURAPID independently produces traction machines, door operators and Operation Panels. SURAPID meets the strictest industrial quality standards and ensures that all products meet the highest industrial quality standards.

SURAPID'S THREE SAFETY PARTS

SURAPID independently produces overspeed governors, safety gears and buffers. We have senior experts in research and development of safety parts of elevators. Meanwhile, SURAPID is equipped with advanced testing equipment to strengthen safety inspection.



OFFER GOOD SERVICES AT ANY TIME

No one knows your equipment better than SURAPID.

Locally trained and globally networked professional engineers

We have a skilled first-rate maintenance team and a globally networked expert team to provide whole-process services.

Custom-made, Personalized, and IT-based

The information center, the technical team and the spare part center form a "three-in-one" complete service system, which provides customers with personalized maintenance solutions and responds to customer demands around the clock.

Globally consistent maintenance procedure standard

We provide a globally consistent, standard, and professional maintenance procedure standard to ensure that all customers can enjoy the same high-quality services.



Officially certified sufficient supply of original parts

SURAPID has built a long-term strategic partnership respectively with Youmai, Fuwode, Fuxin and Youmai Heavy Industry, which are all subsidiaries of NEW XI'AO, to ensure the stable supply of parts.


Higher Maintenance Standard

Preventive maintenance, semimonthly, quarterly, semiannually, and yearly adjustment and maintenance, and maintenance as required.


SURAPID I 07

ENERGY CONSERVATION AND EMISSION REDUCTION

Effectively reduce carbon emission of buildings.











Energy-saving Traction Machine

SURAPID elevators use permanent magnet synchronous gearless traction machines, do not need excitation, and boast a low starting current, high drive efficiency and a more reasonable structure.

Independent Manufacturing of Core Parts of Traction Machines

- SURAPID is the only one which can independently produce magnetic steel, driving sheaves, brakes, bases, and rotors in the industry.
- The hardness difference of driving sheaves is less than 15HBW, which greatly extends the service life of steel ropes.

The traction machine features low heat generation and no demagnetization.

- After the traction machine runs at full load for one hour, its temperature rise is not more than 90k, which is 15k lower than the national standard.
- The ambient temperature of machine rooms is optimized, which increases the service life of the traction machine.

High Drive Efficiency and Accurate Encoder Feedback

- The drive efficiency reaches 87%.
- Use German Heidenhain encoders featuring accurate feedback. Eliminate the vibration of elevators caused by interference.

Low Operation Noise

- The ultra-quiet brake effectively reduces noise by 5-10dB and is better than imported brakes of the same kind in braking force.
- The noise of non-load traction machines is 52dB and the noise of machine rooms can be controlled to be less than 75 dB. Industry-leading in noise control.

SURAPID I 09

INTELLIGENT TECHNOLOGY

Efficiently transport passengers for you.

A meaningful life resides in not only achievements but also spiritual improvement. Elevators are not just used for hoisting but should be more intelligent. The Suda passenger elevator is a classic intelligent elevator.





Intelligent Control System

The control system adopts a dedicated VVVF system and a modular structure fully designed by computer to ensure efficient, comfortable, safe operation of elevators.

Advanced Technologies

- Independently developed all control panels, converters, and monitors. Hold 106 patents.
- Adopt integrated double-32-bit-microcomputer control It is easy to debug and can be debugged remotely.
- After power failure or failure recovery, automatically learn the angle of the encoder.
- Upgrading of handheld equipment of the OMUDebugging of the mobile phone app



Smart Factory

The function of 6-minute intelligent automatic inspection of Operation Panels ensures traceability of prod-

The grade of dust resistance can reach level 100,000 for lean production of PCBs.


Through automatic input and testing, the influence of human factors on production is removed.

Reliable Quality

The elevators pass more than 100 strict tests before leaving the factory. The fault rate is lower than 0.3%. Achieve the group control of 8 elevators.

All pass strict environment, electronics, machinery, and EMC tests.

SURAPID 112 SURAPID | 11



Emergency Evacuation Device for Power Failure

When the normally running elevator stops suddenly because of a sudden power failure, the device acts immediately and drives the elevator to move to the leveling position at a low speed. After leveling, it gives a voice prompt while opening the door to evacuate passengers.

Remote Monitoring Management System

The monitoring center achieves the monitoring, control and report of elevators and manages their key operation functions via remote networking to ensure safety use of elevators through remote monitoring and management.



Access System

The access system controls the use of elevators. The elevator can be used only after user recognition, which greatly enhances the safety of building management and makes users feel safer.

- (1) Face Recognition
- ② Voice Recognition
- 3 QR Code Recognition
- 4 Fingerprint Recognition
- (5) IC Card Recognition



SURAPID | 13

SAFETY PROTECTION

Aways ensure your safety.

The light curtain protects you every time when you take a SURAPID elevator.

Protect your safety and ensure timely evacuation after every sudden power failure.

Every solution puts the safety of users first.

Safe Door Operator

Its motor is a permanent magnet synchronous variable frequency motor, which increases the output torque of the motor, features low noise and high efficiency, and greatly reduces energy consumption.

Safe and Energy-saving

- In case of sudden power failure, the opening door will always close slowly under protection.
- The permanent magnet synchronous motor is used, which increases the output torque of the motor and greatly reduces power consumption.

Reliable Operation and a Low Power Failure Rate


- 3 million reliability verification tests (the national standard is 2 million tests)
- Have a national-level laboratory
- 400 thousand sets are being used in construction sites. Boast an extremely low power failure rate.

Suitable for the Complicated Environment of Construction Sites

- With a wide voltage range, it can adapt to a voltage fluctuation of 20% to withstand the unstable voltage of construction sites.
- The ingress protection grade of motors reaches IP 54. The relative humidity is 98%. It can adapt to the environment of construction sites with splashed water, lots of dust, and mortar.

High Efficiency, Low Noise and No Need for Debugging

- The shortest time for opening door is 2 seconds. The noise is only 50dB. Have high operation efficiency and low noise. After
- on-site installation, there is no need for debugging.



German IF Industrial Design Award

PERSONALIZED DESIGN

Show the infinite appeal of buildings

It is SURAPID's responsibility to make your building space more user-friendly.
We put ourselves in your shoes in all aspects, such as appearance and user experiences.

Customizable Car Decoration

We offer over 100 choices for car decoration. We can also develop custom-made products according to customer demands to offer exclusive car designs for customers.



Anti-nuisance X

To avoid mischiefs or error car instructions, the computer cancels abnormal instructions by logical judgement on load to ensure normal elevator operation and comfortable user experiences.



Passed the Stress Test for Cars

Independently developed the car system. The stress analysis of elevators needs to be conducted by ANSYS for cars. Moreover, the cars also must pass the test of elevators conducted by the elevator test tower.



Accessible Function ×

Fully meet the requirements of the Code for Accessibility Design GB50763 and the European EN81-70 Standard and provide better, safer services for disabled users.



Remarks: **XOptional function**




PASSENGER ELEVATOR SERIES

CHUANCHENG SERIES | MACHINE-ROOM
PASSENGER ELEVATORS
JIERUI SERIES | MACHINE-ROOM-LESS PASSENGER ELEVATORS
JIEYUN SERIES | PANORAMIC ELEVATORS
JIERUN SERIES | HOSPITAL ELEVATORS





CHUANCHENG SERIES | MACHINE-ROOM **PASSENGER ELEVATORS**



Products

Load: 630~1600kg Speed:1.0~2.5m/s

Product Configuration

Traction Machine: permanent magnet synchronous gearless traction machine

Operation Panel: integrated double-32-bit-microcomputer Door Operator: permanent magnet variable frequency

Door Protection: light curtain

① Full Digital Control

The elevators adopt 32-bit full digital control to integrate elevator control and driving, featuring rich functions, intelligent control, low noise, etc.

② Energy-saving Traction Machine


The elevators use permanent magnet synchronous gearless traction machines, change traditional design, do not need excitation, and boast a low starting current, high drive efficiency and a more reasonable structure.

3 Efficient Permanent Magnet Variable Frequency Door Operator

The elevators have authoritative certifications for their main technical indexes and safety performance, featuring a compact structure, energy conservation, environmental protection, reliable operation, easy installation, low noise, etc.

Personalized Decoration

Based on customers' architectural styles and installation environment, SURAPID gives full play to their characteristics to offer exclusive elevator decoration to them.



CAR DECORATION Standard Configuration



Car Model: XTQ01-2101 Integrated Suspended Ceiling:XTQ04-268D Hairline-finish stainless steel veneering Back Wall: Short-hairline-finish stainless steel Side Wall: Short-hairline-finish stainless steel Front Wall: Short-hairline-finish stainless steel

Light Source: LED Floor: XTQ07-31 B1-7705(PVC)

HUMAN-MACHINE INTERFACE Standard Configuration



Standard Configuration Of Operation Panels XCP2-F

Monitor: 6.4' LED+ acrylic Operation Panel: hairline-finish stainless steel

Monitor

Button





6.4' LED+ acrylic

BS34R Black character

STANDARD CONFIG-URATION OF CALL-ING BOARDS

Monitor Button





XBS34H

4.3' LED+ acrylic





XHB12-C

Black Plastic Frame Hairline-finish stainless steel panel

CAR DECORATION/HUMAN-MACHINE Interface—optional Configuration



Optional Configuration of Calling boards





XHB23-B

LCD Screen: PC large window LED segment code display Button:BR34K Button Calling board: black plastic frame hairline-finish stainless steel panel

Operation Panel: XCP12-L Integrated Suspended Ceiling:XTQ04-268D spray coating steel plate (ivory) Back Wall: spray coating steel plate (ivory) Side Wall: spray coating steel plate (ivory) Front Wall: spray coating steel plate (ivory) Light Source: LED

OTHER DECORATION **Optional Configuration**

Ceiling—Optional Configuration

XTQ04-204D

Spray coating steel plate (light camel) + acrylic



Floor—Optional Configuration

XTQ07-68 **PVC** Series



XTQ04-219D

Spray coating steel plate (pearly silver) + acrylic light guide panel



XTQ07-71 **PVC Series**



XTQ04-1101D

Spray coating steel plate (pearly silver) + integrated light box



XTQ07-210 PVC Series



XTQ04-254D

Hairline-finish stainless steel, acrylic decoration+ downlight



XTQ07-24 Marble Series



Handrail—Optional Configuration

XTQ06-01







XTQ06-01A

XTQ06-16



XTQ07-23 Marble Series



Floor: XTQ07-31 B1-7705(PVC)

CAR DECORATION **Titanium Gold Series—optional Configuration**

XTQ01-1710-3-T

Ceiling: titanium gold hairline-finish stainless steel veneering+ acrylic+ downlight 【XTQ04-254D(T)】 Back Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (XIZI-1013)

Side Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (Fixed width of 500)

Floor: parquet, Yihua TM111-D01+TM-746A (Dark Emperador) [XTQ07-211]

Front Wall: titanium gold hairline-finish stainless steel Operation Panel: integrated, titanium gold hairline-finish stainless steel

XTQ01-226-2-T

Ceiling: spray coating steel plate (crown gold) + acrylic+ LED downlight [XTQ04-226D (XCY11)] Back Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (HM-0138)

Side Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (Fixed width of 500)

Floor:903C+TM-746A (PvC) [XTQ07-226]

Front Wall: titanium gold hairline-finish stainless steel Operation Panel: integrated, titanium gold hairline-finish stainless steel



XTQ01-1803-1-T

Ceiling: titanium gold hairline-finish stainless steel veneering+ acrylic+ downlight [XTQ04-24(T)] Back Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (HM-2002-6(A))

Side Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (Fixed width of 500)

Floor: PVC parquet, TM-746A Emperador+TM-111-D01 [XTQ07-511]

Front Wall: titanium gold hairline-finish stainless steel Operation Panel: integrated, titanium gold hairline-finish stainless steel

XTQ01-1805-1-T

Ceiling: titanium gold hairline-finish stainless steel veneering+ acrylic+ downlight 【XTQ04-24(T)】 Back Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (SY-982)

Side Wall: titanium gold hairline-finish stainless steel+ titanium gold mirror-finish etched stainless steel (Fixed width of 500)

Floor: PVC parquet, TM-746A Emperador+TM-111-D01 [XTQ07-511]

Front Wall: titanium gold hairline-finish stainless steel Operation Panel: integrated, titanium gold hairline-finish stainless steel





CAR DECORATION Platinum Series—Optional

XTQ01-1710-2

Ceiling: hairline-finish stainless steel veneering+ acrylic+ downlight 【XTQ04-254D】 Back Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (XIZI-1013) Side Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (Fixed width of 500) Floor: PVC parquet, Yihua TM111-D01+TM-746A(Dark Emperador) [XTQ07-211] Front Wall: hairline-finish stainless steel Operation Panel: integrated, hairline-finish stainless

XTQ01-226-2

Ceiling: spray coating steel plate (light coffee) + acrylic+ LED downlight 【XTQ04-226D 】 Back Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (HM-0138) Side Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (fixed width of 500) Floor:903C+TM-746A (PVC) [XTQ07-226] Front Wall: hairline-finish stainless steel Operation Panel: integrated, hairline-finish stainless steel





XTQ01-1803-1

Ceiling: mirror-finish stainless steel+ acrylic+ downlight [XTQ04--24]

Back Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (HM-2002-6(A)) Side Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (fixed width of 500) Floor: PVC parquet, Yihua 903C+Yihua 903D

[XTQ07-212]

Front Wall: hairline-finish stainless steel Operation Panel: integrated, hairline-finish stainless steel

XTQ01-1805-1

Ceiling: mirror-finish stainless steel+ acrylic+ downlight [XTQ04--24]

Back Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (SY-982)

Side Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel (fixed width of 500)

Floor: PVC parquet, Yihua 903C+Yihua 903D

[XTQ07-212]

Front Wall: hairline-finish stainless steel Operation Panel: integrated, hairline-finish stainless








JIERUI SERIES | MACHINE-ROOM-LESS PASSENGER ELEVATOR

Series: Suitable For Wells With A Short Headroom Height Series: Suitable For Wells With A Narrow Construction Width



Products

Product Configuration

Load: 630~2000kg Speed:1.0~2.5m/s Traction Machine: permanent magnet synchronous gearless traction machine

Operation Panel: integrated double-32-bit-microcomputer control

Door Operator: permanent magnet variable frequency door operator

Door Protection: light curtain

① Energy-saving Traction Machine

The elevators use permanent magnet synchronous gearless traction machines, change traditional design, do not need excitation, and boast a low starting current, high drive efficiency and a more reasonable structure.

③ Save Space


The machine-room-less passenger elevator doesn't need a machine room on the top of buildings. All equipment is installed in the well. So, it saves building space and costs.


② Closed-loop Vector Microcomputer Control System

It uses double 32-bit CPUs, and adopts a multi-module coordinated control mode to ensure smoother, accurate, comfortable operation of elevators.

② Diverse Monitors

Both car and hall monitors use LCD screens, which feature clear undistorted images, a large visual area and diverse novel styles.





Products


Load: 800kg, 1000kg, 1050kg

Speed: 1.0-1.75 m/s

Product Configuration

Traction Machine: ultrathin traction machine

Operation Panel: integrated double-32-bit-microcomputer control Door Operator: permanent magnet variable frequency door operator Door Protection: light curtain





Simplify Architectural Design

As it doesn't need a machine room and there is no load on the top of the well, architects enjoy more flexibility and convenience in design.

Use Space Effectively

As it doesn't need a machine room, it can increase the usable space of buildings to the greatest extent possible.

Save Construction Costs

The machine-room-less elevator can save the time, materials, and costs of construction.

Easy and Efficient Installation

Preinstallation and efficient installation ensure quick construction. Only smaller hoisting equipment is needed.

Easy to Maintain

It is easy to maintain the traction machine at the top of the car.

MACHINE-ROOM-LESS PASSENGER ELEVATOR

Series: suitable for wells with a short headroom height and a narrow construction width

Ultrathin Traction Machines

SURAPID elevators use ultrathin traction machines, do not need excitation, and boast a low starting current, high drive efficiency and a more reasonable structure.

Front Encoder

A common encoder is used, which is more applicable

Motion of Rotatory Shafts

The motion of rotatory shafts meets the service conditions of bearings better than the motion of fixed shafts. Have a longer service life.

Split-type Installation of Driving Sheaves

It is easier to maintain driving sheaves and rotors installed in a split-type way than those installed in an integrated way.

Choose Quiet, Quick-fit Brakes

It is easy to adjust and maintain at construction sites.

Process Verification of Ultrathin Traction Machines

Tensile Test of Steel Ropes (Deformation)



Deformation of Rear Bases 0.31mm Deformation of Rotors 0.32mm



CAR DECORATION/ HUMAN-MACHINE INTERFACE **Standard Configuration**

Ceiling: XTQ04-254D+acrylic decoration Back Wall: hairline-finish stainless steel Side Wall: hairline-finish stainless steel Floor:XTQ07-31 B1-7705(PVC) Recommended Front Wall: hairline-finish stainless steel



Standard Configuration of Operation **Panels** XCP2-A

Monitor: rectangular Window: 6.4' LED+ acrylic Button: emitting white light Operation Panel hairline-finish stainless steel

Monitor



Monitor: amplified window 6.4' LED+ acrylic Button: emitting white light

Button



BS34D Emitting white light

11111 11111

Standard Configuration of Calling boards

Monitor

LCD Screen: 4.3' LED Button: BS34F, emitting white light Hall button: hairline-finish stainless steel



Button

4.3' LED BS34F



Single Elevators/Parallel and Split-type



XHB12-A Parallel and Integrated

OTHER DECORATION **Optional Configuration**

Ceiling—Optional Configuration



Hairline-finish stainless steel veneering on right and left sides + spray coating steel plate (Baihecai) veneering at the front and the back+ spray coating steel plate (lusterless black) + translucent acrylic+ downlight



XTQ04-23 Mirror-finish stainless steel frame Translucent acrylic panel



Floor—Optional Configuration

XTQ07-68 **PVC** Series



XTQ07-71 **PVC Series**



XTQ07-210 **PVC Series**



XTQ07-24 Marble Series



XTQ07-1306 Marble Series



XTQ07-23 Marble Series



XTQ06-01B

Handrail—Optional Configuration

XTO06-01

SURAPID 通道 1350 公 Jierui Series| Machine-room-less Passenger Elevators

HUMAN-MACHINE INTERFACE—OPTIONAL CONFIGURATION

Optional Monitors of Operation Panels

Boards

Optional Monitors of Calling



6.4' LED









Red World

Dance of Wind

Operation Panel

Segment Code Display







Operation Panel XCP12-F



Monitor



6.4' LED Display+Acrylic

Button



BS34R Black Character

Monitor



6.4' LED Display+Acrylic

Button



BS34R Black Character

CAR DECORATION Hotel Series—Optional Configuration

XTQ01-1351

Ceiling: XTQ04-1351 stoving finish steel plate+ gold foil+ downlight+ crystal ceiling light Back Wall: Sapele wood veneering+ leather+ rose gold mirror-finish stainless steel trim strip Side Wall: rose gold mirror-finish stainless steel+ leather+ rose gold mirror-finish stainless steel trim


Floor: XTQ07-1351 stone parquet Handrail: XTQ06-1351 wood handrail Recommended Front Wall: rose gold mirror-finish stainless steel

Remark: the style of crystal lamps varies according to crystal lamps available in the market.



XTQ01-1360

Ceiling: XTQ04-1360 Sapele+ frosted stainless steel+ gold foil+ downlight
Back Wall: Sapele wood veneering+ ebony+ rose gold mirror-finish stainless steel trim strip+ rose gold mirror-finish stainless steel+ artistic glass
Side Wall: Sapele wood veneering+ ebony+ rose gold mirror-finish stainless steel trim strip+ rose gold mirror-finish stainless steel+ artistic glass
Floor: XTQ07-1360 stone parquet
Recommended Front Wall: rose gold mirror-finish stainless steel




XTQ01-1362

Ceiling: XTQ04-1362 titanium gold hairline-finish stainless steel+ translucent marble panel+ spray coating steel plate+ downlight
Back Wall: ebony veneering+ titanium gold hairline-finish stainless steel trim strip+ titanium black mirror-finish stainless steel
Side Wall: ebony veneering+ titanium gold hairline-finish stainless steel trim strip+ honeycomb marble panel

Floor: XTQ07-1360 stone parquet

XTQ01-113-2

Suspended Ceiling: XTQ04-128 translucent marble+ stoving varnish steel plate
Side Wall: titanium gold mirror-finish stainless steel+ titanium black mirror-finish stainless steel
Back Wall: titanium gold mirror-finish etched stainless steel+ titanium black mirror-finish stainless steel+ titanium gold mirror-finish stainless steel
Floor: XTQ07-66 stone parquet
Recommended Front Wall: titanium gold mirror-finish stainless steel





CAR DECORATION Residence Series—Optional Configuration

XTQ01-1709

Ceiling: XTQ04-230D hairline-finish stainless steel veneering+ acrylic+ downlight

Back Wall: hairline-finish stainless steel+ mirror-finish stainless steel

Side Wall: hairline-finish stainless steel+ mirror-finish stainless steel

Handrail: XTQ06-01B circularly-brushed 304 stainless

Floor: XTQ07-31 single color PVC

Recommended Front Wall: hairline-finish stainless

XTQ01-79

Ceiling: XTQ04-89 hairline-finish stainless steel frame+ mirror-finish stainless steel ceiling+ acrylic+ downlight

Back Wall: mirror-finish etched (XIZI-1013) +

hairline-finish stainless steel

Side Wall: mirror-finish stainless steel+ hairline-finish stainless steel

Handrail: XTQ06-01B round circularly-brushed stainless steel tube

Floor: XTQ07-30 parquet PVC

Recommended Front Wall: hairline stainless steel

XTQ01-1710

Ceiling: XTQ04-254D hairline-finish stainless steel veneering+ acrylic+ downlight

Back Wall: hairline-finished stainless steel+ mirror-finish etched stainless steel

Side Wall: hairline-finished stainless steel+ mirror-finish stainless steel

Handrail: XTQ06-01B circularly-brushed 304 stainless

Floor: XTQ07-31 single color PVC

Recommended Front Wall: hairline-finished stainless steel

XTQ01-1711

Ceiling: XTQ04-231D hairline-finish stainless steel veneering+ acrylic+ downlight

Back Wall: hairline-finish stainless steel+ mirror-finish etched stainless steel

Side Wall: hairline-finish stainless steel

Handrail: XTQ06-01B circularly-brushed stainless

Floor: XTQ07-31 single color PVC

Recommended Front Wall: hairline-finished stainless









JIEYUN SERIES | PANORAMIC ELEVATORS

Have Lots of Fun while Riding Elevators

Provide Great Panoramic Views

With varied designs and high quality, the Jieyun Series can meet design requirements of different buildings, naturally integrate into buildings, and endow buildings with specific characters and vitality.

Intelligent Control System

The control system adopts the VVVF system and a modular structure fully designed by computer to ensure efficient, comfortable, safe operation of elevators.

Advanced Technologies

- Independently developed all control panels, converters, and monitors. Hold 106 patents.
- Adopt integrated double-32-bit-microcomputer control
- It is easy to debug and can be debugged remotely.
- After power failure or failure recovery, automatically learn the angle of the encoder.
- Upgrading of handheld equipment of the OMU
- Debugging of the mobile phone app




Smart Factory

- The function of 6-minute intelligent automatic inspection of Operation Panels ensures traceability of products.
- The grade of dust resistance can reach level 100,000 for lean production of PCBs.
- Through automatic input and testing, the influence of human factors on production is removed.

Reliable Quality

- The elevators pass more than 100 strict tests before leaving the factory. The fault rate is lower than 0.3%.
- Achieve the group control of 8 elevators.
- All pass strict environment, electronics, machinery, and EMC tests.





Remote Monitoring Management System ×

The monitoring center achieves the monitoring, control and report of elevators and manages their key operation functions via remote networking to ensure safety use of elevators through remote monitoring and management.

Focus on Details Personalized Design

The Jieyun panoramic elevators adopt multiple design styles, focus on details, perfectly integrate into buildings through rich personalized styles, create harmonious flexible spaces, and complement buildings.



A Wide Field of Vision Offering Great Panoramic Views

With 270° views, the large safety glass enables you to enjoy outside beautiful views and urban prosperity from different angles.

Early Door Opening Device

When the elevator approaches the door opening area, it will open the door in advance and slowly move to the leveling position under the safe condition.





SURAPID 147 Jieyun Series Panoramic Elevators SURAPID 148

CAR DECORATION Square (Standard Configuration)






Model: XTQ08-681 (Economical Optional Configuration) Suspended Ceiling: XTQ04-254D

XTQ08-68-1

Top and Bottom Covers: hairline-finish stainless steel
Suspended Ceiling: XTQ04-71 (hairline-finish stainless steel+ acrylic)
Side and Back Walls: hairline-finish stainless steel+ laminated tempered glass
Front Wall: hairline-finish stainless steel
Handrail: XTQ06-01B
Floor: XTQ07-31 (PVC)

Optional Ceilings



Optional Handrails

XTQ06-01A XTQ06-01B

Optional Floors

XTQ07-71
PVC
Series

XTQ07-68
PVC
Series

XTQ07-1306
Marble
Series

XTQ07-210

XTQ07-23



CAR DECORATION Round (Standard Configuration)

XTQ08-71

Top and Bottom Covers: simple top and bottom covers
Suspended Ceiling: XTQ04-701 (hairline-finish stainless steel+ downlight)
Side and Back Walls: hairline-finish stainless steel+ laminated glass
Handrail: XTQ06-22A
Floor: XTQ07-31 (PVC)



XTQ08-72

Remark: optional round standard configuration for all panoramic elevators



Optional Ceilings

XTQ04-129

XTQ04-17



Optional Floors

(PVC)

XTQ07-G53 (Marble)



PVC

Series

CAR DECORATION Rhombic (Standard Configuration)



XTQ08-303

Top and Bottom Covers: simple top and bottom

Ceiling: XTQ04-129A (long-hairline-finish stainless steel+ acrylic) Side and Back Walls: long-hairline-finish stainless steel+ laminated tempered glass (6+6) Handrail: XTQ06-25D Floor: XTQ07-31 (PVC)

Optional Ceilings

XTQ04-700



XTQ04-17




Optional Floors

XTQ07-301A (PVC)



HUMAN-MACHINE INTERFACE Standard Configuration





Standard Configuration of Calling boards XHB12-A

LCD Screen: 4.3'LED Button: XBS34H Calling board: hairline-finish stainless steel

Main Landing Lock









Button



29 29

Standard Configuration of **Operation Panels XCP12-A**

Monitor: 6.4' LED Button: emitting white light Operation Panel: hairline-finish stainless steel

Monitor



Button



BS34D



SURAPID | 51 Jieyun Series | Panoramic Elevators Jieyun Series | Panoramic Elevators | SURAPID | 52

HUMAN-MACHINE INTERFACE Optional Configuration

Optional Operation Panels

Monitor



7' TFT

Button



BS34E

Touch Button Optional Emitting Color: white



Optional Calling Boards Monitor

4.3' TFT

Monitor

4.3' TFT-LCT Red World

11111 11111

Operation Panel XCP12-A

Calling Board XHB12-A

Panel: mirror-finish stainless steel







Operation Panel XCP12-A

Calling Board XHB12-A

Panel: titanium gold mirror-finish stainless steel







Optional Panel Materials of Operational Panels

1.Hairline-finish stainless steel 2.Mirror-finish stainless steel 3.Titanium gold mirror-finish

Optional Panel Materials of Calling boards

1.Hairline-finish stainless steel 2.Mirror-finish stainless steel 3.Titanium gold mirror-finish

Button: Emitting white color

Optional Emitting Color: red

Button Pannel Materials

1.Hairline-finish stainless steel 2.Mirror-finish stainless steel 3.Titanium gold mirror-finish

Optional Calling Style XHB11-C

Monitor: XHB11-C (LED Display) Button: BR34E/BR34E(B) button

Panel: hairline-finish/mirror-finish 304 stainless steel





Optional Integrated Operation Panel XCP2-A2

Monitor



6.4' LED Display

Button

BS34D

Optional Monitors of Operation Panels



6.4' LED



7' TFT



6.4' STN



10.4' TFT

Optional Buttons of Operation Panels



BR32A (Only Frosted Effect)





XBR27D(K)





BR32A(B)

Effect)

(Only Frosted





CAR DECORATION **Optional Configuration Square Panoramic Car Series**

 \times The pictures are for illustrative purposes only and may differ from actual products.



XTQ08-691-3

Top and Bottom Covers: simple top and bottom covers Suspended Ceiling: hairline-finish stainless steel+ acrylic+ laminated glass

Back Wall: laminated glass

Side Wall: hairline-finish stainless steel+ laminated glass Handrail: round mirror-finish stainless steel tube handrai fixed on the floor

Floor: PVC (XTQ07-31)

Recommended Front Wall: hairline-finish stainless steel+ laminated glass



XTQ08-1502

Top and Bottom Covers: stoving varnish steel plate (bluish silver) + hairline-finish stainless steel+ mirror-finish stainless steel

Suspended Ceiling: hairline-finish stainless steel+ acrylic+ LED downlight (XTQ04-82)

Back Wall: hairline-finish stainless steel+ laminated glass Side Wall: hairline-finish stainless steel+ laminated glass Handrail: round mirror-finish stainless steel tube handrail fixed on the floor (XTQ06-221)

Floor: PVC (XTQ07-1307)

Recommended Front Wall: hairline-finish stainless steel



XTQ08-691

Top and Bottom Covers: simple top and bottom covers Suspended Ceiling: hairline-finish stainless steel+ acrylic (XTQ04-88)

Back Wall: laminated glass Side Wall: hairline-finish stainless steel+ laminated glass Handrail: round mirror-finish stainless steel tube handrail fixed on the floor (XTQ06-692D)

Floor: PVC (XTQ07-31)

Recommended Front Wall: hairline-finish stainless steel



XTQ08-611

Top and Bottom Covers: mirror-finish etched stainless steel (HM-95)

Suspended Ceiling: mirror-finish stainless steel frame+ acrylic+ downlight (XTQ04-08)

Back Wall: mirror-finish stainless steel+ laminated glass Side Wall: mirror-finish stainless steel+ laminated glass Handrail: round mirror-finish stainless steel tube handrail fixed on the floor (XTQ06-21B)

Floor: PVC (XTQ07-60)

Recommended Front Wall: mirror-finish stainless steel

CAR DECORATION Optional Configuration Round Panoramic Car Series CAR DECORATION Standard Configuration Rhombic Panoramic Car Series

XTQ08-712

Top and Bottom Covers: hairline-finish stainless steel+ acrylic (non-luminous) Suspended Ceiling: stoving

varnish steel plate (aurora silver) + acrylic+ LED downlight (XTQ04-705A) Back Wall: hairline-finish stainless steel+ laminated glass

Side Wall: hairline-finish stainless steel Handrail: round mirror-finish stainless steel tube handrail fixed on the floor (XTQ06-22D) Floor: PVC(XTQ07-31)

Recommended Front Wall: hairline-finish stainless steel



XTQ08-721

Top and Bottom Covers: stoving varnish steel plate (aurora silver+ pearly gold) Suspended Ceiling: aurora silver stoving varnish steel plate+ ivory acrylic+ LED downlight (XTQ04-721) Side and Back Walls: short-hairline-finish stainless steel+ laminated alass Handrail: XTQ06-22D Floor: PVC (XTQ07-721) Recommended Front Wall: hairline-finish



XTQ08-1505

Top and Bottom Covers: gilded frosted stainless steel+ frosted Suspended Ceiling: stoving varnish steel plate (shiny silver and titanium gold) + silk-screen acrylic+ LED downlight (XTQ04-G1505) Back Wall: titanium gold frosted stainless steel+ laminated glass Side Wall: titanium gold frosted stainless steel+ titanium gold mirror-finish etched stainless ste Handrail: flat titanium gold hairline-finish stainless steel handrail+ titanium gold mirror-finish stainless steel support grounded on the floor (XTQ06G1505) Floor: stone parquet (XTQ07-G1505)

Recommended Front Wall:

steel

titanium gold frosted stainless



XTQ08-1301

stainless steel

Top and Bottom Covers: sandblasting long-hairline-finish stainless steel Suspended Ceiling: hairline-finish stainless steel + acrylic + LED downlight (XTQ04-G1301) Side and Back Walls: hairline-finish stainless steel+ laminated glass Handrail: XTQ06-26C Floor: PVC (XTQ07-G1301) Recommended Front Wall: hairline-finish stainless steel





The pictures are for illustrative purposes only and may differ from actual products.

XTQ08-301

Top and Bottom Covers: stoving varnish steel plate (pearly gold) + decorative LED light

Suspended Ceiling: aurora silver stoving varnish steel plate+ acrylic (XTQ04-301) Back Wall: hairline-finish stainless steel+ laminated glass

Side Wall: hairline-finish stainless steel+ laminated glass

Handrail: XTQ06-25C Floor: PVC (XTQ07-301A) Recommended Front Wall: hairline-finish stainless steel

XTQ08-302

Top and Bottom Covers: stoving varnish steel plate (aurora silver)
Suspended Ceiling: aurora silver stoving varnish steel plate+ acrylic (XTQ4-301)
Back Wall: hairline-finish 304 stainless steel+ laminated glass
Side Wall: hairline-finish 304 stainless steel+ laminated glass
Handrail: XTQ06-25C
Floor: PVC (XTQ07-31)
Recommended Front Wall: hairline-finish stainless steel

SURAPID I 57 Jieyun Series | Panoramic Elevators SURAPID I 58



RAnti-interference Design Eliminating Hidden Dangers

This series fully meets relevant electromagnetic compatibility standards and can effectively avoid the electromagnetic interference between all kinds of precision equipment and elevators signals in medical institutions. It eliminates electromagnetic pollution and meets the demand of modern medical systems.

Emergency Evacuation Device for Power Failure ×

When the normally running elevator stops suddenly because of a sudden power failure, the device acts immediately and drives the elevator to move to the leveling position at a low speed. After leveling, it gives a voice prompt while opening the door to evacuate passengers.




Anti-nuisance **X**

To avoid mischiefs or error car instructions, the computer cancels abnormal instructions by logical judgement on load to ensure normal elevator operation and comfortable user experiences.

Accessible Function *

Provide better, safer services for disabled users.





SURAPID | 59 Jierun Series | Hospital Elevators SURAPID | 60

German IF Industrial Design Award XHB6-A&XHB7-A SURAPID | 61 Jierun Series | Hospital Elevators

PERSONALIZED DESIGN

Show The Infinite Appeal Of Buildings

It is SURAPID's responsibility to make your building space more user-friendly.

SURAPID puts itself in your shoes in all aspects, such as appearance and user experiences.

Super-large Space More Accessible

It fully considers the needs of special crowds. The wide car door and the long car depth enable sickbeds and medical equipment to get in and out of the elevator smoothly and conveniently.



Emergency Call VIP Treatment

In case of emergency, passengers in the car can press this button and then the elevator will respond to your call immediately. The button at a low position is user-friendly for the disabled and children.



Comfortable Personalized Design


The car walls and flooring are easy to clean and durable. With soft lamplight and a few colors, it creates a warm comfortable space for patients and doctors to the greatest extent possible.





The Jierun hospital elevators start, stop, and run smoothly, creating very comfortable user experiences for patients. The design strengthening safety performance effectively, and lowers the rate of accidental breakdowns.

The Jierun hospital elevators are specially customized for hospitals, medical institutions, rehabilitation centers, nursing homes, etc. Considering the characteristics of medical venues, we give priority to safety and health. While being efficiently transported to their destinations, patients can also have a smooth and comfortable experience.



Products

Load Range: 1,000-2,000kg

Speed Range: 1.0~4.0m/s

Product Configuration

Traction Machine: permanent magnet synchronous gearless traction machine Operation Panel: integrated double-32-bit-microcomputer control Door Operator: permanent magnet variable frequency door operator Door Protection: light curtain

SURAPID 163 Jierun Series | Hospital Elevators SURAPID 164

CAR DECORATION/ HUMAN-MACHINE INTERFACE Standard Configuration

Suspended Ceiling: XTQO4-H17spray coating steel plate (light grey) + acrylic+ injection molding parts
Back Wall: hairline-finish stainless steel
Side Wall: hairline-finish stainless steel

Handrail: XTQ06-16 flat hairline-finish stainless steel handrail

Floor: XTQ07-31 Yihua B1-7705(PVC)

Recommended Front Wall: hairline-finish stainless steel



Standard Configuration of Operation Panels XCP12-A

Monitor: 6.4' LED Button: emitting white light Operation Panel: hairline-finish stainless steel

Monitor



6.4' LED

Button



BS34D



29 29

Standard Configuration of Calling boards XHB12-A

Monitor

LCD Screen: 4.3'LED Button: XBS34H, emitting white light Calling board: hairline-finish stainless steel



Button



XBS34H



OTHER OPTIONAL DECORATION

Suspended Ceiling-Optional





Handrail—Optional Configuration



Floor—Optional Configuration

XTQ07-68 PVC Series





Landing Door Decoration-Optional

XTQ09-08P Short-hairline-finish Stainless Steel





XTQ09-11P Mirror-finish Stainless Steel





XTQ09-1377P Mirror-finish Etched (HM-4)





XTQ09-114P Titanium Gold Mirror-finish Etched Stainless Steel





SURAPID | 65 Jierun Series | Hospital Elevators Jierun Series | Hospital Elevators SURAPID | 66

HUMAN-MACHINE INTERFACE—OPTIONAL

Optional Monitors of Operation Panels







7' TFT

Operation Panel XCP12-L

Monitor



6.4' LED Segment Code Display

Button



BS34D

Calling Board XHB12-L

Panel:Mirror-finish stainless steel







Monitor



4.3'LED Segment Code Display



4.3'TFT-LCD Dance of Wind

Operation Panel XCP12-L

Monitor



6.4' LED Segment Code Display

Button



BS34D

Calling Board XHB12-L

Panel: Titanium mirror-finish stainless







Optional Panel Materials of Operational Panels

- 1. Hairline-finish stainless steel
- 2. Mirror-finish stainless steel
- 3. Titanium mirror-finish

Optional Panel Materials of Calling boards

- 1. Hairline-finish stainless steel
- 2. Mirror-finish stainless steel
- 3. Titanium mirror-finish

Button: Emitting white color

Optional Emitting Color: red

Button Pannel Materials

- 1. Hairline-finish stainless steel 2. Mirror-finish stainless steel
- 3. Titanium mirror-finish
- **Optional Calling** Style XHB11-C

Monitor: XHB11-C (LED Display) Button: BR36E\BR36E(B) button

Panel: hairline-finish/mirror-finish 304 stainless steel





7' TFT

Optional Monitors of Operation

Optional Integrated Operation

Button

BS34D

Panel XCP2-A

Monitor

MAN S ARREST

6.4' LED Display



Panels







Optional Buttons of Operation Panels

10.4' TFT




BR32A (Only Frosted Effect)







新印料集 全











CAR DECORATION Optional Configuration

XTQ01-H1391

Suspended Ceiling: XTQ04-H21 spray coating steel plate (pearly silver) + arc-shaped acrylic

Back Wall: mirror-finish stainless steel+ hairline-finish stainless steel

Side Wall: mirror-finish stainless steel+ hairline-finish stainless steel

Handrail: XTO06-16 flat hairline-finish stainless steel

Floor: XTO07-31 Single Color PVC

Recommended Front Wall: hairline-finish stainless

XTQ01-H1390-1

Suspended Ceiling: XTQ04-H1392 hairline-finish stainless steel + LED downlight

Back Wall: hairline-finish stainless steel Side Wall: hairline-finish stainless steel

Handrail: XTO06-16 flat hairline-finish stainless steel

Floor: XTO07-31 Single Color PVC

Recommended Front Wall: hairline-finish stainless steel





XTQ01-H1392


Suspended Ceiling: XTQO4-H1392 hairline-finish stainless steel+ acrylic+ LED downlight Back Wall: mirror-finish etched stainless steel (HM-983)

Side Wall: mirror-finish etched stainless steel (HM-983)

Handrail: XTQ06-04 three-tube mirror-finish stainless steel handrail

Floor: XTQ07-1392 parquet PVC

Recommended Front Wall: hairline-finish stainless



Suspended Ceiling: XTQ04-H1352 spray coating steel plate (crown gold)+ acrylic

Back Wall: titanium gold mirror-finish etched stainless steel (HM-0138) + hairline-finish stainless steel

Side Wall: titanium gold mirror-finish etched stainless steel (HM-038) + hairline-finish stainless steel Handrail: XTQ06-01B round circularly-brushed stainless steel tube

Floor: XTQ07-1352 parquet PVC

Recommended Front Wall: hairline-finish stainless





FUNCTION LIST OF PASSENGER ELEVATORS

↑ Operation Function

| Full Collective Selective Operation | After comprehensively analyzing and judging upward and downward hall call signals, floor-selecting instructions in the car and other various signals, the elevator will automatically prioritize signals consistent with the operation direction of the motor and respond to them in sequence. |
|--|---|
| Full-load Non-stop | When the car reaches the preset full-load value, the elevator will enter the full-load non-stop state, not respond to the hall call any more, turn on the full-load light in the hall, and directly respond to the instructions in the car to move to the designated floors. |
| Reinitialized Operation | When position signals are not retained or the car position is uncertain after the recovery of power supply, the elevator will move to the terminal landing for repositioning. After the repositioning, the position monitor shows the position of the elevator. And then, the elevator resumes normal operation. |
| Correcting Operation | During elevator operation, the system automatically corrects small landing and car position errors, and minimizes the landing error. |
| Well Position Self-learning | It has the well position self-learning function and stores well position signals. When running normally, the elevator achieves landing and stops directly. |
| One-push Well Self-learning | The elevator can achieve one-push well self-learning by pushing the LRN DIP switch, which facilitates installation and debugging on construction sites. |
| Automatic Cancellation of Opposite Direc- tion Instructions | When moving upwards or downwards, the elevator can automatically cancel the instructions which are opposite to the current moving direction. |
| Cancellation of False Instructions | When an instruction has been registered, users can cancel the registered instruction by repeatedly pressing the button before the elevator starts. However, after the elevator starts, the system forbids the cancellation of registered signals to ensure the safety of passengers. |
| Cancellation of Waiting Time for Door Closing | When the door maintains a full-open state in the delayed door opening stage under the automatic condition, users can press the door close button to immediately close the door in advance. |
| Door Open Button | The operation panel in the car is equipped with a touch button for passengers to flexibly open the door according to their needs. |
| Door Close Button | The operation panel in the car is equipped with a touch button for passengers to flexibly close the door according to their needs. |
| Door Open Button Light | When the door open button is pressed, the button light will be turned on, which indicates a successful response. |
| Door Close Button Light | When the door close button is pressed, the button light will be turned on, which indicates a successful response. |
| Separate Control of Landing and Car Doors | The waiting time for door opening caused by hall calls is longer than that caused by instructions made in the car according to statistics. This function improves the overall operation efficiency by independently adjust the time for keeping the doors open when the elevator responds to the calls and instructions. |
| Door Opening by Hall Call | When the door is closing normally, the elevator will open the door again if the direction of the pressed hall button is the same as the moving direction of the elevator. |
| Automatically Return to Main Landing | When there is only a single elevator, the main landing can be set according to the actual needs of the building. If there isn't call or instruction registration within a preset time, the car will automatically return to the main landing, close the door and be on standby. Usually, the main landing is set on the floor having heavy traffic or on the first floor. |
| Car Roof Inspection Operation | The car roof is equipped with an inspection cabinet, which makes inspection and maintenance safer and more convenient. |
| | |

| Starting Torque Compensation | To ensure a better experience when the elevator starts, the system calculates the load of the car and achieves optimization through starting torque compensation. | | | | | |
|--|---|---|--|--|--|--|
| Function of Not Registering Opposite Direc- tion Instructions | When the elevator is moving upwards or downwards, the instructions, which are opposite to the current moving direction, can be set to be unable to register. | | | | | |
| Positioning-free | In case of power failure, parameter changes and faults, the drive automatically captures magnetic poles without the need of manual intervention for positioning before working again. | | | | | |
| Removal of Currents by Ramp | During the use of the permanent magnet synchronous motor, after the elevator slows down and stops, the holding current of the motor is removed by ramp to avoid abnormal noise of the motor during the process. | • | | | | |
| Recognition of Sticky Hall Buttons | The system can recognize a sticky hall button and automatically remove its sticky call to prevent the elevator from being unable to close the door because of the sticky hall button. | • | | | | |
| Reduce Carrier Frequency for Maintenance | Under the condition of ensuring basic functions of running elevators, to protect the drive base to the greatest extent possible, an operation mode is added, which automatically adjusts the carrier frequency to 6KHz during inspection operation. | | | | | |
| Zero-speed Stop During Inspection | This function greatly reduces the damage to the band-type brake of the traction machine caused by the non-zero-speed stop during inspection. | | | | | |
| Car Arrival Bell | It is equipped on the top of the car. When the elevator arrives at the landing floor, it will make clear and melodious sounds to remind passengers that they have arrived. | | | | | |
| Open the Door in Advance | When approaching the door area, the elevator will open the door in advance and slowly move to the leveling position under the safe condition. | • | | | | |
| Automatic Relevelling | When deviation between the car sill and the landing sill caused by passengers getting in and out of the elevator and other reasons which lead to load changes exceeds a certain value, the elevator will automatically relevel to move the car to the accurate leveling position. | 0 | | | | |
| Parallel/ Group Control Function | This function is used for the group control of two or more than two elevators of the same model. It enables the elevator group to automatically choose the most suitable response to avoid the repeated stop of elevators, to shorten passengers' waiting time, and to improve the operation efficiency. | | | | | |
| Door Open Button | When more passengers enter the car and need to extend the door opening time, they can press the door open button on the operation panel. When an elevator of the group control system keeps door open, the system will automatically transfer the hall call signal allocated to this elevator to other elevators. | 0 | | | | |



Safety Functions

| Overload Protection | When the load of the car exceeds the allowable rated load, the overload buzzer will produce a buzzing sound as a signal of overload. At the time, it shows overload, the door of the car doesn't close and the elevator can't start. | • |
|--|---|---|
| Overheat Protection of Drive Equipment | When the temperature of the motor exceeds the preset value as the temperature of the machine room is too high or the motor generates heat during operation, the elevator will automatically enter the protection state and stop at the closest landing. | • |
| Terminal Landing Protection | When the elevator arrives at the terminal landing but its speed doesn't reduce to the preset value, the system will slow it down forcibly to protect its safe operation. | • |

Standard Optional

SURAPID | 71 SURAPID 172

FUNCTION LIST OF PASSENGER ELEVATORS

| Car Door Opening Protection | When the elevator can't open the door within the preset time because of reasons like mechanical blocks, it will cancel the hall and in-car call signals and move to the closest landing to release passengers. | • | | | |
|---|---|---|--|--|--|
| Car Door Closing Protection | When the elevator can't close the door within the preset time because of reasons like mechanical blocks and can't detect door closing signals after closing the door three times, the elevator will automatically enter the protection state. When the elevator detects normal closing of the door, it will resume normal operation. | | | | |
| Delayed Car Door Closing Protection | When the door opening time exceeds the preset time as the hall button is pressed or there are other reasons, the elevator will close the door forcibly to respond to other signals. When the door doesn't close properly after the elevator closes the door forcibly several times, the elevator will stop operation and opens the door, and the hall and in-car call signals will be automatically cancelled. When the elevator detects the normal closing of the door, the elevator resumes normal operation. | • | | | |
| Door Closing Torque Protection | If the reverse resistance exceeds the preset torque value when the door is closed, the elevator will open the door again. | • | | | |
| Light Curtain Door Protection | The infrared lights emitted from the light curtain device scan all objects entering the detection area to form a sensitive and safe infrared screen. Once the infrared lights are interfered, the elevator door will reopen quickly and won't hurt passengers, thus ensuring that passengers get in and out of the elevator safely and conveniently. | • | | | |
| Fault Self-diag- nosis | When the control system automatically detects the abnormal phenomena of the control loop, it stops the elevator automatically to ensure passenger safety. | • | | | |
| Function of Monitoring Power Grid Wave Filtering | If the voltage of the power grid fluctuates continuously within a period, the system will automatically give an alarm. | • | | | |
| Function of Detecting Speed Feedback | Once the system detects the difference between the actual speed and the given speed, it will automatically disconnect the safety circuit and give an alarm. | • | | | |
| Function of Detecting Band-type Brake Feedback | It monitors the signals of the band-type brake relay during the whole process. When it detects the difference between the actual condition of the band-type relay and the preset instruction, the elevator stops operation. | • | | | |
| Function of Detecting Contactor Feedback | Whether the elevator is on standby or is running, the system will detect the condition of the output relay. Once the contactor is in an abnormal state, the system will give an alarm. | • | | | |
| Short Circuit Detection of Door Locks | Whether the elevator is on standby or is running, the system will detect the condition of the output relay. Once the contactor is in an abnormal state, the system will give an alarm. | • | | | |
| Door Bypass Device | For elevator inspection, a unique bypass device can be connected to the landing and car door locks by a short circuit. After the short circuit, the elevator can only be operated for inspection or emergency electric operation, with the prompt of the audible and visual alarm system during operation. (Standard Configuration for Machine-room-less Gearless Traction Machines) | | | | |
| UCMP Function | It prevents the car which keeps the door open in the unlocking area from unintended movements without instructions. | • | | | |
| Terminal Floor Protection | When the elevator arrives at the terminal floor but the speed doesn't reduce to the preset value, the system will slow it down forcibly to ensure its safety operation. | • | | | |
| Band-type Brake Torque Inspection | The elevator system can inspect the brake torque automatically or manually. | • | | | |
| | | | | | |

▼▲ Human-Machine Interface

| Hall and In-car Direction Light Prompt | There are arrow-shaped indicator lights on the operation panel and the calling board for passengers to learn the moving direction of the elevator conveniently. | • |
|--|---|---|
| Digital Hall/In-car Display | The operation panel and the calling board of each floor show the landing of the elevator by 16-segment digital display at any time for passengers to know the current position of the elevator. | • |
| Hall and In-car Digital LCD | The operation panel and the calling board of each floor show the landing of the elevator by digital LCD for passengers to know the current position of the elevator. | 0 |
| Hall and In-car Color LCD | The operation panel and the calling board of each floor adopt high-end color LCD. | 0 |

| In-car Multimedia Color Display | The in-car operation panel adopts high-end color LCD and can play multimedia information according to user needs. | 0 |
|------------------------------------|---|---|
| Hall Arrival Light/Bell | Installed in the hall, it reminds passengers that the elevator is arriving by the upward and downward indicator lights and the built-in audio device. | 0 |

♠ Emergency Functions

| 7/V | 3 ····· 3 · ························· | | | |
|--|---|---|--|--|
| Emergency Electric Operation of the Machine Room | The control cabinet of the machine room is provided with an emergency electric operation device for emergency rescue. | • | | |
| In-car Emergen- cy Lighting | The in-car emergency lighting device starts during power failure. | • | | |
| In-car Alarm Button | In special circumstances, passengers can press the in-car alarm button to inform the outside world. | | | |
| Intercom | In special circumstances, passengers can maintain voice communication with the machine room and the monitoring center by intercom devices installed on the operation panel, the car roof, and the car platform. | • | | |
| Prompt of Fire | When entering the state of fire control, the elevator displays prompt information in the car. | • | | |
| Emergency Fire Control | After receiving the fire alarm signal when a fire starts in the building, the system will cancel all instructions and calling signals, drive the elevator to directly return to the fire exit floor and open the door to evacuate passengers. After the elevator successfully stops at the main landing, the control system provides the signal of successful emergency landing for the fire control center while displaying the fire prompt. | • | | |
| Emergency Fireman Service | After the successful emergency landing, the elevator returns to the fire exit floor and evacuate passengers. Then, the elevator enters an independent service state for firemen to use. | 0 | | |
| Emergency Power Source Operation | After elevators are connected to the emergency power source of customers in case of power failure, cars in the group control system move to the designated (next) landing one by one and open the doors to release passengers. According to user needs, the group control system can designate some elevators for normal service operation. After the power source returns to normal, all elevators automatically resume normal operation. | | | |
| Emergency Evacuation Device for Power Failure | When the normally running elevator stops suddenly because of a sudden power failure, the device acts immediately and drives the elevator to move to the leveling position at a low speed. After leveling, it gives a voice prompt while opening the door to evacuate passengers. | 0 | | |
| Integrated ARD Function | In case of power failure, the elevator can move the car to the next landing and open the door to release passengers through an external UPS equipment. After its power source returns to normal, the elevator automatically resumes normal operation. | 0 | | |
| Integrated HSD Function | In case of power failure, the external UPS equipment acts as the working power source of the system. The elevator moves the car to slide towards underloading direction by inching release of the band-type brake of the traction machine to the next landing and then opens the door to release passengers. | 0 | | |
| Automatic Leveling | When the elevator stops in the non-levelling area because of faults and overhauls, the elevator will slowly move to the leveling area if it meets safety requirements for starting after the faults are solved and the overhauls are completed. Then the elevator opens the door automatically and resumes normal operation while pacifying passengers by voice. (The pacifying device is optional.) | • | | |
| Leveling and Door Opening Function | When the elevator stops in the unlocking area for any reasons, passengers can open the car and landing doors manually in the car, or use the triangle key to open the car and landing doors. | • | | |

(Energy Conservation Function

| In-car Fan and Lighting Control | Under the circumstance of not receiving any operation instructions, the elevator will enter the energy-saving mode and turn off in-car lights and fans in the preset time after closing the door. | • |
|------------------------------------|---|---|
|------------------------------------|---|---|

Standard Optional

SURAPID 173 **SURAPID** | 74

FUNCTION LIST OF PASSENGER ELEVATORS

Stop Switch

It is also known as the parking switch. After the key switch equipped on the designated floor acts, the elevator will return to the designated floor after completing all instructions and enter an energy-saving mode. It will turn off lights in the car and turn on the indicator light of the stop switch



Special Operation

| Driver Operation | The elevator enters the driver operation state by operating the switch in the operation panel. The driver can conduct management related to the number of passengers in the car, hall call responses and door opening and closing. | | | | |
|--|--|---|--|--|--|
| Friendly Prompt in the Driver State | When the elevator is in the driver operation state, the buzzer in the operation panel will buzz and the corresponding button in the car will flicker if there is hall call registration. | | | | |
| Direct Driving in the Driver State | After the elevator enters the driver state and the NSB button in the operation panel is pressed, the elevator doesn't respond to hall call signals and directly moves to the destination floor. | 0 | | | |
| Down Collective Selective Operation | The elevator is provided with upward hall buttons on the first floor or the main landing. Other floors are only provided with the downward hall buttons. After comprehensively analyzing and judging the hall call signals and in-car instruction signals in the building, the elevator will automatically prioritize signals consistent with the operation direction of the elevator and respond to them in sequence. | 0 | | | |
| Automatic Parking | When all elevators in one group control system in one building are on standby, they will automatically stop on different floors of the building to improve the response speed of the elevator group to calls. | • | | | |
| Anti-nuisance Protection | To avoid non-load operation, the computer cancels abnormal instructions by logical judgement on load. This function can avoid mischiefs or error car instructions. If there is only one passenger in the car but too much requests are registered, all requests will be cancelled after the nuisance is detected. Then, the elevator will respond to correct floor signals. | 0 | | | |
| Anti-crime Protection | The elevator enters the anti-crime mode through the setting of parameters or the triggering of external switches. The elevator stops on the predesignated floor and opens the door for guards or receptionists to check. | | | | |
| Password Floor Service | This function can use buttons in the car to set a password for authority management of designated floors in the building to manage the entry and exit of people. | | | | |
| Smart IC Card System | This function achieves the authority management of designated floors through the card reading system in the car and the hall. This system is only for the intelligent management of people getting in and out of the elevator but can't integrate with other IC card management systems in the building. | | | | |
| Earthquake Operation | When an earthquake occurs, the system will cancel all instructions and calling signals after receiving seismic signals. The elevator will open the door on the closest floor to release passengers and stop. Users need to provide seismic signals. | | | | |
| Dining Hall Floor Waiting | It allocates a longer time for floors with lots of passengers like dining halls to meet the higher demand for transport. | 0 | | | |
| Landing Prompt | When passing a landing, the elevator reminds passengers of the landing by a buzzer, providing services for special groups like blind persons. | 0 | | | |
| Startup and Shutdown at a Fixed Time | This function enables the elevator to start and shut down at a fixed time to automatically control the lock of the elevator. | | | | |
| Announcement Module | When the elevator slows down and levels, the elevator will announce the approaching landing to remind passengers. | | | | |
| Pacifying Passen- gers by Voice | When breaking down, the elevator pacifies passengers by voice in the car. | 0 | | | |

| Dedicated Air Conditioners | It is specially designed for air conditioning in the car and is an independent circulation system. Through automatic atomization of condensate water, automatic change of working modes for ultra-high water levels, water level limit protection, air purification and other functions, it keeps air temperature, humidity, cleanness and speed comfortable for people to create a cool and refreshing car space. | | | |
|--|---|---|--|--|
| Anti-interference Function for Maintenance | when a person presses the hall button, it displays the floor number where he is. It doesn't display the floor number after the button is released. This function ensures that the maintenance is not | | | |
| Independent Service | It is an independent service state designed to meet special customer demands. After entering the independent service state, the elevator won't respond to hall call signals, and can only close and open the door and operate by manual control. | • | | |
| Independent VIP Function | After this function is used, the elevator is exclusively used by passengers and the hall calling board doesn't display floor numbers while the operation panel in the car shows floor number normally to keep the information of their destination floors secret. | 0 | | |
| Retain Calling Instructions in Overload Protection | In the mode of overload protection, it can retain the registered calling instructions and doesn't | | | |
| Optimization of Door Opening | When reopening the door, the elevator cancels the time for keeping the door open but directly closes the door to improve efficiency. | | | |
| Resetting and Rescue Function | | | | |
| Indication of Elevator Allocation | It indicates passengers to take the corresponding elevator by the hall arrival light to make it convenient for them. | 0 | | |
| Retain Calling Instructions in Overload Protection | In the mode of overload protection, it can retain the registered calling instructions and doesn't cancel them. | 0 | | |
| Waterproof Detection Contactor | | | | |
| Rush Hour Service | It is specially used for alleviating the traffic peak in the building. In the morning rush hour, when the passenger load of all elevators in service exceeds the preset value (usually 50%) in the hall, the elevators enter this mode immediately. And this mode will be kept during the rush hour. (This function is only available for parallel and group control elevators. It is unavailable for a single elevator.) | 0 | | |

▼ Monitoring Functions

| Building Elevator Monitoring Interface | g Elevator ring Interface The elevator can provide users' intelligent building management system with discrete elevator operation status signals, which mainly include running directions, floor numbers and safety information. | | | | | |
|--|---|---|--|--|--|--|
| Series Interface of Building Monitoring | The elevator can provide users' intelligent building management system with elevator operation status signals in the RS-485 communication mode. The main signals include running directions, floor numbers and safety information. | 0 | | | | |
| Monitoring System for Communities | The monitoring system for communities is an intelligent management system which achieves the comprehensive monitoring of elevators by microcomputer in the community and can provide data for intelligent management of buildings. | 0 | | | | |
| Remote Monitor- ing System for Elevators | The machine room is provided with a remote communication device, which transmits the real-time information of elevator operation to the remote monitoring center and achieves the remote elevator information transmission and failure warning. It reduces the time for removing elevator faults. Meanwhile, the in-car audio and video functions are available. It can provide a client interface for users' elevators in the monitoring area. | C | | | | |
| BA Interface Panel | The building elevator monitoring interface (BA interface panel) function collects elevator signals, such as position signals, upward and downward movement signals, failure signals, stop signals and safety circuit signals, at the Input end. The signals are outputted from the Output end after being processed by encoder and level shifter. The BA system can recognize and use the above signals. | 0 | | | | |

Standard Optional

SURAPID 175 SURAPID 176



FREIGHT ELEVATOR SERIES

JIEDA SERIES | FREIGHT ELEVATORS





JIEDA SERIES | FREIGHT ELEVATORS MACHINE-ROOM FREIGHT ELEVATORS

High-performance Traction Machines

The freight elevators use permanent magnetic synchronous traction machines, whose drive efficiency is 20% to 30% higher than that of traditional geared traction machines. They are small in volume, low in energy consumption, steady in operation, low-noise and maintenance-free. They can significantly improve the comprehensive performance of elevators and make elevators more comfortable.

Control System


It adopts an integrated control system and adopts VVVF vector control. The dedicated pattern generator ensures a gentle and smooth speed curve. All significantly improve the comfort level and leveling accuracy of elevators.


Permanent VF Door Operator

It adopts matured VF drive technologies and control logics in the industry. The synchronous door operator ensures that the landing door and the car door opens synchronously. It is sensitive, safe, reliable, and easy to install and maintain.

Coverage (Gearless Traction Machines)

The high-strength car structure and the optimized design of key parts improve the solidness and safety of the overall structure and effectively ensure the safety of freight and passengers.







JIEDA SERIES | FREIGHT ELEVATORS MACHINE-ROOM-LESS FREIGHT ELEVATORS

Perfect Spaces

Through the small design of traction machines and control cabinets, the machine-room-less freight elevator compresses the machine room into the well, which can effectively save space, integrates the elevator with the building and provides more free choices for architectural design. So, it is suitable for more venues.

Efficient Installation

As it doesn't have a machine room, the installation of machine-room-less freight elevators is mainly conducted in the well, which can effectively reduce the installation time and speed up the progress of building work.

Coverage (Gearless Traction Machine)

| Speed(m/s) | | | | |
|------------|------|------|------|------|
| 1.0 | | | | |
| 0.5 | | | | |
| 0.25 | | | | |
| Load(kg) | 2000 | 3000 | 4000 | 5000 |

SURAPID 179 Jieda Series | Freight Elevators SURAPID 180

CAR DECORATION/ HUMAN-MACHINE Interface—Standard Configuration

Suspended Ceiling: spray coating steel plate Ventilation: fan

Lighting: LED

Sill: aluminum alloy (side opening two-speed sliding door); aluminum alloy/ cast iron (center opening two-speed sliding door)

Car Door/ Car Wall: spray coating steel plate Operation Panel/Calling Board: hairline-finish stainless

Floor: aluminum alloy/bent steel plate/ cast iron



Standard Configuration of Operation Panels XCP23-B

Monitor: 6.4' LED Button: emitting white light Operation Panel: hairline-finish stainless steel



Monitor



6.4' LED

Button

Monitor

4.3' LED+

acrylic



BR34J




Floor—Optional



Steel Diamond Plate (Standard)

Standard Configuration of Calling Boards XHB23-B



white light Calling Board: Black plastid frame Hairline-finish stainless steel





Button

BR34K

CAR DECORATION/ HUMAN-MACHINE **Human-Machine Interface—Optional**



Optional Configuration of Operation Panels XCP4-A

Monitor: 6.4 LED Button: BS34D Operation Panel: hairline-finish stainless

Monitor



6.4' LED

Button



BR34D


Floor-Optional



Steel Diamond Plate

Car Door / Car Wal) — Optional

2.Spray Coating Steel Plate (Colors Available)



The color atlas is for illustrative purposes only and may differ from actual products.

FUNCTION LIST OF FREIGHT ELEVATORS

PA Operation Function

| Full-load | When the car reaches the preset full-load value, the elevator will enter the full-load non-stop state, | |
|---|---|---|
| Non-stop | not respond to the hall call any more, turn on the full-load light in the hall, and directly respond to the instructions in the car to move to the designated floors. | • |
| Reinitialized Operation | When position signals are not retained or the car position is uncertain after the recovery of power supply, the elevator will move to the terminal landing for repositioning. After the repositioning, the position monitor shows the position of the elevator. And then, the elevator resumes normal operation. | • |
| Automatic Cancella- tion of Opposite Direction Instructions | When moving upwards or downwards, the elevator can automatically cancel the instructions which are opposite to the current moving direction. | • |
| Door Open and Close Button | The operation panel in the car is equipped with a touch button for passengers to flexibly open and close the door according to their needs. | • |
| Cancellation of False Instruc- tions | When an instruction has been registered, users can cancel the registered instruction by repeatedly pressing the button before the elevator starts. However, after the elevator starts, the system forbids the cancellation of registered signals to ensure the safety of passengers. | • |
| Door Open and Close Button Lights | When the door open and close buttons are pressed, the button lights will be turned on, which indicates a successful response. | • |
| Door Opening by Hall Call | When the door is closing normally, the elevator will open the door again if the direction of the pressed hall button is the same as the moving direction of the elevator. | • |
| Automatically Return to Main Landing | When there is only a single elevator, the main landing can be set according to the actual needs of the building. If there isn't call or instruction registration within a preset time, the car will automatically return to the main landing, close the door and be on standby. Usually, the main landing is set on the floor having heavy traffic or on the first floor. | • |
| Separate Control of Landing and Car Doors | The waiting time for door opening caused by hall calls is longer than that caused by instructions made in the car according to statistics. This function improves the overall operation efficiency by independently adjust the time for keeping the doors open when the elevator responds to the calls and instructions. | • |
| Cancellation of Waiting Time for Door Closing | When the door maintains a full-open state in the delayed door opening stage under the automatic condition, users can press the door close button to immediately close the door in advance. | • |
| Starting Torque Compensation | To ensure a better experience when the elevator starts, the system calculates the load of the car and achieves optimization through starting torque compensation. | • |
| Automatic Relevelling | When deviation between the car sill and the landing sill caused by passengers getting in and out of the elevator and other reasons which lead to load changes exceeds a certain value, the elevator will automatically relevel to move the car to the accurate leveling position. | • |
| Parallel Opera- tion | This function is used for the group control of two elevators of the same model. It enables the elevator group to automatically choose the most suitable response to avoid the repeated stop of elevators, to shorten passengers' waiting time, and to improve the operation efficiency. | 0 |
| Door Open Button | When more passengers or freight enter the car and need to extend the door opening time, they can press the door open button on the operation panel. When an elevator of the group control system keeps door open, the system will automatically transfer the hall call signal allocated to this elevator to other elevators. | 0 |
| Car Arrival Bell | It is equipped on the top of the car. When the elevator arrives at the landing floor, it will make clear and melodious sounds to remind passengers that they have arrived. | 0 |

★ Emergency Functions

| In-car Emergen- cy Lighting | The in-car emergency lighting device starts during power failure. | • |
|--|--|---|
| In-car Alarm Button | In special circumstances, passengers can press the in-car alarm button to inform the outside world. | • |
| Emergency Evacuation Device for Power Failure | When the normally running elevator stops suddenly because of a sudden power failure, the device acts immediately and drives the elevator to move to the leveling position at a low speed. After leveling, it gives a voice prompt while opening the door to evacuate passengers. | С |
| Emergency Electric Operation of the Machine Room | The control cabinet of the machine room is provided with an emergency electric operation device for emergency rescue. | • |
| Intercom | In special circumstances, passengers can maintain voice communication with the machine room and the monitoring center by intercom devices installed on the operation panel, the car roof, and the car platform. | • |

⚠ Safety Functions

| Overload Protection | When the load of the car exceeds the allowable rated load, the overload buzzer will produce a buzzing sound as a signal of overload. At the time, it shows overload, the door of the car doesn't close and the elevator can't start. | • |
|--|---|---|
| Overheat Protection of Drive Equipment | When the temperature of the motor exceeds the preset value as the temperature of the machine room is too high or the motor generates heat during operation, the elevator will automatically enter the protection state and stop on the closest landing. Then, the elevator opens the door, releases passengers safely and turns off the lights and fans in the car. After the temperature returns to normal, the elevator resumes normal operation. | • |
| Terminal Landing Protection | When the elevator arrives at the terminal floor but the speed doesn't reduce to the preset value, the system will slow it down forcibly to ensure its safety operation. | • |
| Car Door Opening Protection | When the elevator can't open the door within the preset time because of reasons like mechanical blocks, it will cancel the hall and in-car call signals and move to the closest landing to release passengers. | • |
| Car Door Closing Protection | When the elevator can't close the door within the preset time because of reasons like mechanical blocks and can't detect door closing signals after closing the door three times, the elevator will automatically enter the protection state. When the elevator detects normal closing of the door, it will resume normal operation. | • |
| Delayed Car Door Closing Protection | When the door opening time exceeds the preset time as the hall button is pressed or there are other reasons, the elevator will close the door forcibly to respond to other signals. When the door doesn't close properly after the elevator closes the door forcibly several times, the elevator will stop operation and opens the door, and the hall and in-car call signals will be automatically cancelled. When the elevator detects the normal closing of the door, the elevator resumes normal operation. | • |
| Car Roof Inspection | The car roof is equipped with an inspection cabinet, which makes inspection and maintenance safer and more convenient. | • |
| UCMP Function | It prevents the car which keeps the door open in the unlocking area from unintended movements without instructions. | • |
| Emergency Fire Control | After receiving the fire alarm signal when a fire starts in the building, the system will cancel all instructions and calling signals, drive the elevator to directly return to the fire exit floor and open the door to evacuate passengers. After the elevator successfully stops at the main landing, the control system provides the signal of successful emergency landing for the fire control center. | С |



Special Operation

| Automatic Parking | When all elevators in one group control system in one building are on standby, they will automatically stop on different floors of the building to improve the response speed of the elevator group to calls. | • |
|---------------------------------------|--|---|
| Direct Driving in the Driver State | After the elevator enters the driver state and the NSB button in the operation panel is pressed, the elevator doesn't respond to hall call signals and directly moves to the destination floor. | 0 |
| Driver Opera- tion | The elevator enters the driver operation state by operating the switch in the operation panel. The driver can conduct management related to the number of passengers in the car, hall call responses and door opening and closing. | 0 |
| Independent Service | It is an independent service state designed to meet special customer demands. After entering the independent service state, the elevator won't respond to hall call signals, and can only close and open the door and operate by manual control. | 0 |

▼▲ Human-Machine Interface

| Hall and In-car Direction Indication | There are arrow-shaped indicator lights on the operation panel and the calling board for passengers to learn the moving direction of the elevator conveniently. | • |
|--|---|---|
| Hall and In-car Digital Display | The operation panel and the calling board of each floor show the landing of the elevator by 16-segment digital display for passengers to know the current position of the elevator. | • |

Walter Human-Machine Interface

| In-car Fan and Lighting Control | Under the circumstance of not receiving any operation instructions, the elevator will enter the energy-saving mode and turn off in-car lights and fans in the preset time after closing the door. | • |
|------------------------------------|--|---|
| Stop Switch | It is also known as the parking switch. After the key switch equipped on the designated floor acts, the elevator will return to the designated floor after completing all instructions and enter an energy-saving mode. It will turn off lights in the car and turn on the indicator light of the stop switch in the hall. | • |

● Standard ○ Optional

SURAPID 183 SURAPID 184




HOME ELEVATOR SERIES

JIESHANG SERIES | HOME ELEVATORS





JIESHANG SERIES | HOME ELEVATORS COMPOSITE STEEL TAPE HOME ELEVATORS



Enable you and your family to enjoy every comfortable experience.

Home is where the heart is, showing richness and simplicity.

It is a great enjoyment to take the Jieshang home elevators every time.



Composite Steel Tape



Space Requirements



Tape Traction Machine

RURAPID NEW **CONTROL CABINET**

Both an Idol and an Expert Win Your Trust by Good Experiences and Solid Strength



Ultrathin




Extremely Quiet



Safety





CAR DECORATION Standard Configuration

XTQ02-21A

Integrated Suspended Ceiling: XTQ04-506D spray coating steel plate (ivory yellow) + LED downlight Side Wall: spray coating steel plate (ivory yellow) Front Wall: spray coating steel plate (ivory yellow) Back Wall: spray coating steel plate (ivory yellow) Floor: XTQ07-31 B1-7705 (PVC)





XTQ06-16

XTQ06-01B

HUMAN-MACHINE INTERFACE Standard Configuration

Standard Configuration Of Operation Panel

LCD Screen: 4.3' TFT Espresso Interface Button: BR36E, acrylic, emitting white light Operation Panel: mirror-finish stainless steel+ black acrylic



Operation Panel Monitor: 4.3' TFT



Operation Panel Button: BR36E

Standard Configuration of Calling boards

LCD Screen: 4.3' LED Button: BR36F, black acrylic, emitting white light Material: mirror-finish stainless steel frame+ black acrylic panel



Calling Board Monitor: 4.3' LED



Optional (Telephone) AFT-QR-11

Operation Panel: XCP16-A

Standard Configuration (Mirror-finish Stainless Steel+ Hairline-finish Panel+ Black Acrylic)





Optional Off-white Acrylic

Calling Board: XHB15-mini

Standard Configuration (Mirror-finish Frame+ Black Acrylic)



Calling Board Button: BR36F

Optional

Off-white Acrylic

Optional Off-white Acrylic

HUMAN-MACHINE INTERFACE Optional Configuration

Operation Panel: XCP4-E



Stainless Steel Mirror-finish



Stainless Steel

Operation Panel: XCP16-A



Champagne Mirror-finish Stainless Steel+ Frosted Panel+ Beige Acrylic



Black Acrylic

Operation Panel Button



BR36E

Calling Board: XHB11-C



Mirror-finish

Mirror-finish Stainless Steel



Titanium Gold Mirror-finish Stainless Steel



BR36E/BR36E(B)

Calling Board: XHB15-mini





Off-white Acrylic



Gold Acrylic



■ XTQ02-2007

Front Wall and Lintel: mirror-finish stainless steel Side Wall: 2 pieces, artistic steel plate (C131 palm leaf vein)

Back Wall: 3 pieces, corner call walls on right and left sides (artistic steel plate (C131 palm leaf vein) inside radius 50mm, width L1), car wall in the middle is a decorative car wall divided into 3 pieces (white mirror-finish ceramic H119+ titanium black mirror-finish (blacker)+ white mirror-finish ceramic H119, lined wood plank for the second decoration) + black metal trim strips on the right and left sides+ hidden aluminum alloy light strip (6,500K)
Split-type Top (XTQ04-B2007): basic car roof (pink RAL9010 light) beautifully-shaped ceiling (white mirror-finish ceramic H119) + black decoration, hidden light strip (6,500K), 2 downlights with uniform light (6,500K)
Floor (XTQ07-B2007): full-sheet printing PVC





■ XTQ02-2103

Front Wall and Lintel: steel plate car wall (fine orange grain spray painting RAL9002) Side Wall: standard pieces, wood grain artistic steel plate t1.2

Back Wall: the car wall in the middle is divided into three pieces (wood grain artistic steel plate t1.2), wood grain artistic steel plate on the right and left sides (width 160mm) +10mm, light strip with broad light (6,000K)

Integrated Ceiling: steel plate roof (fine orange grain RAL9002), hung square roof (white mirror-finish ceramic H119, 160mm from edges) + LED spotlight+ hidden light strip on the back (6,000K)
Handrail: handrail with a rectangular section fixed on

the wall, champagne gold matte stainless steel end+ wood handrail+ hidden light strip (6,000k), 2 pieces Floor: PVC full-sheet printing

■ XTQ02-2106

Front Wall and Lintel: rose gold mirror-finish stainless steel t1.2

Side Wall: 3 pieces, rose gold mirror-finish etched stainless steel in the middle t1.2 (width 350mm), rose gold hairline-finish stainless steel on two sides t1.2 Back Wall: 3 pieces, rose gold mirror-finish etched stainless steel in the middle t1.2 (width 350mm), rose gold hairline-finish stainless steel on two sides t1.2 Suspended Ceiling: rose gold hairline-finish stainless steel t1.2 frame+ acrylic light source

Skirting: none

Floor: PVC full-sheet printing





■ XTQ02-2107

Front Wall and Lintel: spray coating steel plate (RAL9001, fine crepe effect)

Side Wall: two spray coating steel plates (RAL9001, fine crepe effect), even

Back Wall: spray coating steel plate on two sides (RAL9001, fine crepe effect), LED light strip in the middle (width about 10mm, color temperature 3,500k), arch-shaped corner car wall on right and left sides (RAL7046 fine crepe effect, width about 75mm)

Suspended Ceiling: spray coating steel plate (RAL7046, fine crepe effect) frame+ spray coating steel plate (RAL9001, fine crepe effect) roof + LED light strip

Handrail: U-shaped square tube handrail, RAL7046 stoving varnish end cap+ RAL9001 stoving varnish tube, hidden light strip

Floor: PVC full-sheet printing

XTQ02-2102

Front Wall and Lintel: white mirror-finish stainless steel t1.2

Side Wall: 3 pieces, 10mm-wide spray coating trim strip in the middle (matte black RAL9011), spray coating steel plate evenly divided on two sides (plain color RAL1015, fine orange grain) concave trim strip, 3mm higher than spray coating steel plate car wall Back Wall: 3 pieces, 100mm-wide white mirror-finish stainless steel in the middle t1.2, laminated artistic steel plate evenly divided on two sides t1.2 (FL05) Integrated Ceiling: steel plate roof (fine orange grain RAL9002), hung spray coating roof (fine orange grain RAL9002, 160mm from edges) + LED spotlight+ hidden light strip on the back (6,000K) Skirting: spray coating steel plate (matte black RAL9011), 60mm high Floor: PVC





■ XTQ02-1901-2

Front Wall and Lintel: mirror-finish stainless steel t1.2 Side Wall: 2 pieces, mirror-finish stainless steel (width 160mm), Moshushi K349 wood veneering (produced for the second decoration, car wall with a base)

Back Wall: 3 pieces, Moshushi K349 wood veneering+ rose gold mirror-finish stainless steel trim strip, mirror-finish stainless steel on right and left sides t1.2 (width 160mm) (produced for the second decoration, car wall with a base)

Suspended Ceiling: matte black spray coating steel plate+ stitched leather, ivory acrylic+ LED fluorescent lamp, hidden light strip [XTO04-1901-1] Skirting: spray coating steel plate (matte black RAL9011) 60mm high

Floor: PVC (simulated Elite Beige)

FUNCTION LIST OF HOME ELEVATORS

₱ Operation Function

| Full Collective Selective Operation | After comprehensively analyzing and judging upward and downward hall call signals, floor-selecting instructions in the car and other various signals, the elevator will automatically prioritize signals consistent with the operation direction of the motor and respond to them in sequence. | • |
|--|--|---|
| Full-load Non-stop | When the car reaches the preset full-load value, the elevator will enter the full-load non-stop state, not respond to the hall call any more, and directly respond to the instructions in the car to move to the designated floors. | • |
| Reinitialized Operation | When position signals are not retained or the car position is uncertain after the recovery of power supply, the elevator will move to the terminal landing for repositioning. After the repositioning, the position monitor shows the position of the elevator. And then, the elevator resumes normal operation. | • |
| Automatic Cancellation of Opposite Direction Instructions | When moving upwards or downwards, the elevator can automatically cancel the instructions which are opposite to the current moving direction. | • |
| Door Open and Close Buttons | The operation panel in the car is equipped with a touch button for passengers to flexibly open and close the door according to their needs. | • |
| Well Position Self-learning | It has the well position self-learning function and stores well position signals. When running normally, the elevator achieves landing and stops directly. | • |
| Cancellation of False Instructions | When an instruction has been registered, users can cancel the registered instruction by repeatedly pressing the button before the elevator starts. However, after the elevator starts, the system forbids the cancellation of registered signals to ensure the safety of passengers. | • |
| Door Open and Close Button Lights | When the door open and close buttons are pressed, the button lights will be turned on, which indicates a successful response. | • |
| Door Opening by Hall Call | When the door is closing normally, the elevator will open the door again if the direction of the pressed hall button is the same as the moving direction of the elevator. | • |
| Car Arrival Bell | After the elevator arrives at the designated floor of users, the car roof panel gives prompt signals. | С |
| Separate Control of Landing and Car Doors | The waiting time for door opening caused by hall calls is longer than that caused by instructions made in the car according to statistics. This function improves the overall operation efficiency by independently adjust the time for keeping the doors open when the elevator responds to the calls and instructions. | • |
| Cancellation of Waiting Time for Door Closing | When the door maintains a full-open state in the delayed door opening stage under the automatic condition, users can press the door close button to immediately close the door in advance. | • |
| Starting Torque Compensation | To ensure a better experience when the elevator starts, the system calculates the load of the car and achieves optimization through starting torque compensation. | • |
| Door Open Button | When more passengers enter the car and need to extend the door opening time, they can press the door open button on the operation panel. When an elevator of the group control system keeps door open, the system will automatically transfer the hall call signal allocated to this elevator to other elevators. | С |
| Hall Arrival Bell | The arrival bell installed in the hall will inform passengers of getting ready to get in the car before the elevator arrives. | С |
| Down Collective Selective Operation | The elevator is provided with upward hall buttons on the first floor or the main landing. Other floors are only provided with the downward hall buttons. After comprehensively analyzing and judging the hall call signals and in-car instruction signals in the building, the elevator will automatically prioritize signals consistent with the operation direction of the elevator and respond to them in sequence. | 0 |

SURAPID 197 Jieshang Series | Home Elevators | Home Elevators | Home Elevators | SURAPID 198

FUNCTION LIST OF HOME ELEVATORS

♠ Emergency Functions

| In-car Emergency Lighting | The in-car emergency lighting device starts during power failure. | • |
|---|--|---|
| In-car Alarm Button | In special circumstances, passengers can press the in-car alarm button to inform the outside world. | • |
| Emergency Evacuation Device for Power Failure | When the normally running elevator stops suddenly because of a sudden power failure, the device acts immediately and drives the elevator to move to the leveling position at a low speed. After leveling, it opens the door. | • |

(Energy Conservation Function

| Stop Switch | It is also known as the parking switch. After the key switch equipped on the designated floor acts, the elevator will return to the designated floor after completing all instructions and enter an energy-saving mode. It will turn off lights in the car and turn on the indicator light of the stop switch in the hall. | 0 |
|------------------------------------|--|---|
| In-car Fan and Lighting Control | Under the circumstance of not receiving any operation instructions, the elevator will enter the energy-saving mode and turn off in-car lights and fans in the preset time after closing the door. | • |

☑ Monitoring Functions

| Monitoring System for Communities | The monitoring system for communities is an intelligent management system which achieves the comprehensive monitoring of elevators by microcomputer in the community and can provide data for intelligent management of buildings (BA). | 0 |
|--|---|---|
| Building Elevator Monitoring Interface | The elevator can provide users' intelligent building management system with discrete elevator operation status signals, which mainly include running directions, floor numbers and safety information. | 0 |


▽▲ Human-Machine Interface

| Hall and In-car Direction Indication | There are arrow-shaped indicator lights on the operation panel and the calling board for passengers to learn the moving direction of the elevator conveniently. | • |
|---|--|---|
| Announcements | During deceleration and leveling, the elevator reminds passengers of the next landing by voice. | 0 |
| Dedicated Air Conditioners | It is specially designed for air conditioning in the car and is an independent circulation system. Through automatic atomization of condensate water, automatic change of working modes for ultra-high water levels, water level limit protection, air purification and other functions, it keeps air temperature, humidity, cleanness and speed comfortable for people to create a cool and refreshing car space. | 0 |
| In-car LCD | Use an LCD monitor as a high-end monitor in the car. | 0 |

Standard Optional




| Overload Protection | When the load of the car exceeds the allowable rated load, the overload buzzer will produce a buzzing sound as a signal of overload. At the time, it shows overload, the door of the car doesn't close and the elevator can't start. |
|--|---|
| Overheat Protection of Drive Equipment | When the temperature of the motor exceeds the preset value as the temperature of the machine room is too high or the motor generates heat during operation, the elevator will automatically enter the protection state and stop on the closest landing. Then, the elevator opens the door, releases passengers safely and turns off the lights and fans in the car. After the temperature returns to normal, the elevator resumes normal operation. |
| Terminal Landing Protection | When the elevator arrives at the terminal floor but the speed doesn't reduce to the preset value, the system will slow it down forcibly to ensure its safety operation. |
| Intercom | In special circumstances, passengers can maintain voice communication with the machine room and the monitoring center by intercom devices installed on the operation panel, and the car roof. |
| Fault Self-diagnosis | When the control system automatically detects the abnormal phenomena of the control loop, it stops the elevator automatically to ensure passenger safety. |
| Car Door Opening Protection | When the elevator can't open the door within the preset time because of reasons like mechanical blocks, it will cancel the hall and in-car call signals and move to the closest landing to release passengers. |
| Car Door Closing Protection | When the elevator can't close the door within the preset time because of reasons like mechanical blocks and can't detect door closing signals after closing the door three times, the elevator will automatically enter the protection state. When the elevator detects normal closing of the door, it will resume normal operation. |
| Door Closing Torque Protection | If the reverse resistance exceeds the preset torque value when the door is closed, the elevator will open the door again. |
| Delayed Car Door Closing Protection | When the door opening time exceeds the preset time as the hall button is pressed or there are other reasons, the elevator will close the door forcibly to respond to other signals. When the door doesn't close properly after the elevator closes the door forcibly several times, the elevator will stop operation and opens the door, and the hall and in-car call signals will be automatically cancelled. When the elevator detects the normal closing of the door, the elevator resumes normal operation. |
| Function of Detecting Speed Feedback | Once the system detects the difference between the actual speed and the given speed, it will automatically disconnect the safety circuit and give an alarm. |
| Function of Detecting Contac- tor Feedback | Whether the elevator is on standby or is running, the system will detect the condition of the output relay. Once the contactor is in an abnormal state, the system will give an alarm. |
| Function of Detecting Band-type Brake Feedback | It monitors the signals of the band-type brake relay during the whole process. When it detects the difference between the actual condition of the band-type relay and the preset instruction, the elevator stops operation. |
| Car Roof Inspection | The car roof is equipped with an inspection cabinet, which makes inspection and maintenance safer and more convenient. |



| Light Curtain Door Protection | The infrared lights emitted from the light curtain device scan all objects entering the detection area to form a sensitive and safe infrared screen. Once the infrared lights are interfered, the elevator door will reopen quickly and won't hurt passengers, thus ensuring that passengers get in and out of the elevator safely and conveniently. | • |
|--|--|---|
| Light Curtain and Safety Edges for Door Protection | Use double detection means, reliable mechanical safety edges and sensitive infrared breams, to ensure the safety of passengers getting in and out of the car. | 0 |

Standard Optional

SURAPID 199 SURAPID I 100



ESCALATOR AND SIDEWALK SERIES

JIEXUN SERIES | ESCALATORS AND MOVING SIDEWALKS





JIEXUN SERIES ESCALATORS AND MOVING SIDEWALKS
SURAPID CORE PARTS

SURAPID independently produces control cabinets, trusses, drive assembly and step assembly, meets the strictest quality standards and ensures that its products meet the highest quality standards in the industry.



MULTI-LEVEL SAFETY PROTECTION ALWAYS ENSURE YOUR SAFETY


Truss



Step System



Efficient Traction Machine



Diverse Energy-saving Modes

■ Three energy-saving modes available:

VF Low Speed to High Speed:

VF Self-starting (Standstill-Low Speed-High Speed):

Standard Self-starting (Standstill to High Speed):

max 30% of energy max 45% of energy conservation max 50% of energy conservation



COMFORTABLE AND RELIABLE

Efficiently transport passengers for you

Intelligent Microcomputer Control System



Flexible Large Friction Wheel Handrail Drive

New Spatial Curved Aluminum Alloy Handrail Entry

-

High-precision Two-side Guide Rail



Device for Preventing Floor Plates from Overturning





JIEXUN COMMERCIAL ESCALATOR AND MOVING SIDEWALKS

List of Specifications

Basic Specifications

| Туре | Maximum Hoisting Height | Height | Step Width | Handrail Type | Speed | Service Environ- ment | Control Mode | Traction Machine |
|--------------------|-------------------------------|-----------------|----------------------------|------------------|--------|-----------------------------|---|--|
| Escalator | H≤9.6m | 30°/35° | 1000mm/ 800mm/ 600mm | Slim | 0.5m/s | Indoor/ Outdoor | VF low speed to high speed (standard) VF self-starting (optional) | Worm gear operated traction machine/integrat- ed direct drive traction machine FJ/FYD |
| Moving Sidewalk | L≤30m | 10°/11°/ 12° | 1000mm/ 800mm | Slim | 0.5m/s | Indoor | VF low speed to high speed (standard) VF self-starting (optional) | Worm gear operated traction machine/integrat- ed direct drive traction machine FJ/FYD |

Standard Configuration

| Traction | Control | Cover | Skirt | Handrail | Handrail | Front Edge | Step | Thickness | Height of | Comb | Handrail | Handrail |
|--------------------|--|-------|-------------------------|----------|--------------------|---|-------------------------|-----------|-------------|------------------------|----------------------------|------------------------|
| Machine | System | Plate | Panel | Support | Belt | Panel | | of Glass | Balustrades | Plate | Drive | Entry |
| Do- mes- tic | Microcom- puter Panel Control | На | irline-fir ainless S | | Do- mes- tic | Stainless Steel with Square Patterns | Stain- less Steel | 10mm | 930mm | Alumi- num Alloy | Large Friction Wheel | Alumi- num Alloy |

Optional Configuration

| Traction Machine | Cover Plate | Skirt Panel | Handrail Support | Handrail Belt | Front Edge Panel |
|---------------------|--|--|--|---------------|---------------------|
| Joint Venture | SUS304 Hairline-finish Stainless Steel | SUS304 Hairline-finish Stainless Steel | SUS304 Hairline-finish Stainless Steel/ Spray Coating Carbon Steel | Joint Venture | Aluminum Alloy |

